

Straight Cable Runs Only

Decks 1 and 2 have wood posts with composite sleeves. For sleeved posts, the recommended approach is *face-mounted* to prevent damage to the sleeves themselves. Since sleeves can be easily damaged, there is no bending of the cable through corners. Each run must start and stop. All three runs use the same kit.


Use the 300 and 300-C Series:

If the outside diameter of the composite sleeve is 4½" or less, use the 300 Series.

The tensioning device is an Adjust-a-Body® with Hanger Bolt, which lags into the wood post on one end. A Push-Lock® Lag is lagged into the other end.

If the outside diameter of the composite sleeve is greater than 4½", use the 300-C Series.

The fittings are the same as in the 300 Series, with extended length hanger bolt and lag respectively.



Tools needed for 300-C:

- 5/32 drill bit if 1/8" cable, 7/32 if 3/16" cable
- 7/32 drill bit for hanger bolt and lag installation
- 1/4 wrench for turning hanger bolt
- 7/16 wrench for tensioning Adjust-a-Body®
- 3/8 wrench for installing Push-Lock® Lag
- Cable cutting tool



Series 300-C Kits

Cable Length	1/8" cable	3/16" cable
	PART NO.	PART NO.
5'	30005-C	30005-C6
10'	30010-C	30010-C6
15'	30015-C	30015-C6
20'	30020-C	30020-C6
25'	30025-C	30025-C6
30'	30030-C	30030-C6
40'	30040-C	30040-C6
50'	30050-C	30050-C6