

# Face Mount



## Cable Runs on a Pitch

Top posts are often corner posts, which may require the stair run to connect to the *face* of the post. The top and bottom of the cable run would be connected perpendicular to those posts, and only the intermediate posts would be drilled on the angle for the cable to run through.

### Use the 500-W Series.

The tensioning device is an Adjust-a-Body® with Threaded Eye, which attaches via mounting screw to the lag eye. A Push-Lock® with Threaded Eye attaches the same way to the other end.

The 500-W Series can be used to go up a stair and across a landing by inserting post protector tubes (order CS-TUBE separately) in the break-over post. The tube will prevent the cable from carving a groove into your post where it exits at an angle.



### Series 500-W Kits for Wood Posts

Cable Length	1/8" cable PART NO.	3/16" cable PART NO.
5'	50005-W	50005-6W
10'	50010-W	50010-6W
15'	50015-W	50015-6W
20'	50020-W	50020-6W
25'	50025-W	50025-6W
30'	50030-W	50030-6W
40'	50040-W	50040-6W
50'	50050-W	50050-6W

### Tools needed for 500-W Series:

- 5/32 drill bit if 1/8" cable, 7/32 if 3/16"
- 9/32 drill bit for Lag Eye installation
- 7/16 wrench for tensioning Adjust-a-Body®
- 5/32 hex wrench to tighten mounting screws
- Cable cutting tool
- If using Post Protector Tubes, 1/4 drill bit